





Patent Pending Assembly  
Instruction For 53860/53863



- 1 - LED Disc
- 2 - Connection Cord
- 3 - Driver with 2 step on-off switch


Surface Mount Installation

Step One




Using hands, separate outer aluminum shell from LED lamp

Step Two



Using included hardware and a screw driver, secure outer aluminum shell to cabinet surface

Step Three



Feed connecting cord through a pre-drilled hole in the cabinet surface or through the cut-out of the outer aluminum shell. Secure LED lamp into outer aluminum shell.


Recessed Installation

Step One




Using hands, separate outer aluminum shell from LED lamp

Step Two



Cut out from the bottom of the cabinet a hole using a 2.5" hole saw.

Step Three



Feed connecting cord through the hole in cabinet and secure LED lamp.